


Injury Assessment with Physical Surrogates

Presented by:
Nicholas Shewchenko

Presented for:
Blast Injury Testing Conference IV
Arlington, VA April 6, 2005



© Biokinetics and Associates Ltd., Ottawa, Canada 2005
www.Biokinetics.com

Injury Assessment Considerations

Injury
-type
-severity
-mechanisms

Threat environment
-external body loading
-temporal
-magnitude

Prioritization
-exposure + severity
-trade-offs vs. consequences

Requirements



BITC April 6th, 2005


Surrogate Development

Types

- biological samples*
- biological models*
- physical models*
- numerical models*
- hybrid models*

Considerations

- accuracy*
- 3R (repeatability, reproducibility, robustness)*
- cost, ease of use*
- maintenance*
- calibration*
- validation*



BITC April 6th, 2005

Surrogate Development

What is known?


- injury vs. insult*
- response data:*
 - biomechanical*
 - physiological*

Simplifications

- abs/rel measures*
- biofidelity*
- anthropometry*
- anthropomorphism*

Design

- Specifications*
 - biofidelity*
 - measures and instrumentation*
 - accuracy*
 - geometric*



BITC April 6th, 2005

Physical Surrogates – Head Injury


DEFENCE ballistic



Injuries:
 -focal and diffuse
 -acute/mild
 -skull fracture, tissue disruption



Threats:
 -ballistic impacts
 -blunt impact
 -global acceleration



BITC April 6th, 2005

Head Surrogate for Ballistic Impact


Biomechanics



Ref: Bass



Ref: Bass



Ref: Bass; Dummy Peak Impact Pressure (kPa)

Cranial and facial bone fracture tolerances

Pressure measurement with Hybrid III skull compared to cadaver impacts

Injury risk associated with measured skull pressure



BITC April 6th, 2005

Head Surrogate for Ballistic Impact

Surrogate




Test method for ballistic helmet injury risk assessment



Headform capable of measuring applied force



Forces from force transducers correlated to injury risk relationship






BITC April 6th, 2005

Head Surrogate for Ballistic Impact

Surrogate



Headform response to ballistic impact with 9 mm FMJ on flat plate



BITC April 6th, 2005


Head Surrogate for Concussions

SPORTS Football




Head to head collisions resulting in concussed and non-concussed player

No injury tolerances available for mild head injuries




Kinematics obtained from field



BITC April 6th, 2005


Head Surrogate for Concussions

SPORTS Football




Inertial head response measured in lab re-enactments


$$HIP = 4.50 a_x \int a_x dt + 4.50 a_y \int a_y dt + 4.50 a_z \int a_z dt + 0.016 \alpha_x \int \alpha_x dt + 0.024 \alpha_y \int \alpha_y dt + 0.022 \alpha_z \int \alpha_z dt$$



3-2-2-2 linear/angular data



Strong correlation between HIP and concussion




BITC April 6th, 2005


Head Surrogate for Blast Loading

DEFENCE EBW


Mannequin for Assessment of Blast Incapacitation and Lethality



Threat characterization




Injury tolerance



BITC April 6th, 2005

Head Surrogate for Blast Loading

DEFENCE EBW



MABIL
Instrumented
head to measure
peak pressure
and impulse +
optical




Video of blast loading with MABIL
protected and unprotected




BITC April 6th, 2005

Head Surrogate for Blast Loading




MABIL head ear canal pressures for various protective equipment



BITC April 6th, 2005

Head Surrogate for Blast Loading


DEFENCE EBW



Hybrid III linear head accelerations for various protective equipment




Ref: FTSS




BITC April 6th, 2005

Physical Surrogates - Neck


VEHICLE SAFETY



Surrogate kinematics crucial to head/neck injury assessment



Neck biofidelity based on kinematics of volunteers



BITC April 6th, 2005



Physical Surrogates - Neck

VEHICLE SAFETY

Surrogate neck allows for change in position




Neck to meet flexion, extension, lateral and torsional biofidelity corridors



BITC April 6th, 2005

Torso Surrogate for Ballistics


DEFENCE ballistic



Threat: Ballistic loading provides combined focal and distributed loading depending on projectile and armour

Mechanism: Chest wall motion transfers impact energy to internal organs

Biomechanics: Animal models and PMHS, injuries and biofidelity




BITC April 6th, 2005

Torso Surrogate for Ballistics


Current biomechanical studies compared to anticipated threats

Parameter	Min.	Max.
Mass (g)	100	1000
Velocity (m/s)	10	80
Diameter (mm)	50	125




BITC April 6th, 2005

Torso Surrogate for Ballistics






Injury criteria compared to behind armour loading conditions



BITC April 6th, 2005

Torso Surrogate for Ballistics


- Reproduce biomechanical response of chest wall
→ *as simple as possible*
- Define injury thresholds
 - *deflection max*
 - *velocity / acceleration max*
 - *viscous criterion*
 - *energy/momentum transfer*



BITC April 6th, 2005

Torso Surrogate for Ballistics





- Approach: Reproduce the biomechanical response of the human thorax for behind armour loading conditions



BITC April 6th, 2005

Biofidelity

- Research studies
 - Bir, 2000 (frontal cadaver)*



BITC April 6th, 2005

Torso Surrogate for Ballistics


DEFENCE ballistic





Other considerations:

- targeting
- fitment
- support
- ease of use
- durability

Instrumentation



Evaluation of body armour performance for ballistics




BITC April 6th, 2005

Torso Surrogate for Blast

DEFENCE EBW





MABIL: Evaluation of body response to blast loading by measurement of chest wall acceleration and applied pressure



BITC April 6th, 2005

Torso Surrogate for Blast


DEFENCE blast



Prediction of lung injury

MABIL torso response to blast loading


BITC April 6th, 2005



Leg Surrogate for Blast Protection

DEFENCE blast AP

- CLL (Complex Lower Leg)
- For development and evaluation of protective footwear against AP blast
- Produced under license with DRDC
- recognized by the NATO HFM-089 / TG-024



CLL components and test methodology

BITC April 6th, 2005



Leg Surrogate for Blast Protection

DEFENCE blast




DRDC

CLL response to AP mine blast



CLL standardized test methodology



BITC April 6th, 2005

Leg Surrogate for Blast Protection

DEFENCE blast AV




Courtesy of WTD 91


CLL fitted to HY III for AV mine blast testing



Non-frangible surrogate legs with impact biofidelity



PMHS and surrogate leg biofidelity




BITC April 6th, 2005

Leg Surrogate for Blast Protection


DEFENCE blast AV



CLL response to simulated AV mine blast




CLL with upper tibia load transducer



Typical injury tolerance data for vehicle safety studies

BITC April 6th, 2005




Leg Surrogate for Blast Protection

DEFENCE blast AV



Surrogate validation



No protection


STATUS
MODE
PLAYBACK
FRAME #
TIME OF FRAME
POSITION
EVENT NUMBER
STOP
SETUP
F/32G RECORD
SHUTTER SPEED
TRIGGER POINT
STOP A
F/32G PLAT
50



With protection

STATUS
MODE
PLAYBACK
FRAME #
TIME OF FRAME
POSITION
EVENT NUMBER
STOP
SETUP
F/32G RECORD
SHUTTER SPEED
TRIGGER POINT
STOP A
F/32G PLAT
50


Test results with CLL



BITC April 6th, 2005


Surrogate Development - Summary

- ▶ Define the problem (injuries, threats)
- ▶ Prioritize requirements and define constraints
- ▶ Quantify biofidelity needs
- ▶ Quantify injury criteria based on tolerance
- ▶ Define biomechanical predictors of injury
- ▶ Identify transducer and measurement needs
- ▶ Develop and validate surrogate
- ▶ Use surrogate for validated loading regimes



BITC April 6th, 2005

Engineered Solutions for Impact Protection



BITC April 6th, 2005